## AFSC 2A6X4 AIRCRAFT FUEL SYSTEMS CAREER FIELD EDUCATION AND TRAINING PLAN

This change is effective immediately. This change is the equivalent of publication of a new CFETP. Compliance with AFI 36-2201, para 4.11.6.1. and other training policies and documentation is required. CFETP 2A6X4, April 1999, is changed as follows:

1. Write in changes:

<u>Page</u>	<u>Paragraph</u>	<u>Column</u>	<u>Action</u>					
29	A2.17.3.1.	4(A)	Change from "2b" to "b"					
29	A2.17.3.2.	4(A)	Change from "2b" to "b"					

- 2. Replace page 30 with the revised page 30. This page adds common aircraft ground handling and servicing tasks as mandated by the CSAF Logistics Review.
- 3. After required actions in paragraph 1 and 2 above have been completed, file this change cover page in the back of the CFETP.

BY ORDER OF THE SECRETARY OF THE AIR FORCE

OFFICIAL

MICHAEL E. ZETTLER, Lieutenant General, USAF DCS/Installations and Logistics

## SPECIALTY TRAINING STANDARD

## Change 2, CFETP 2A6X4, October 2001

	2. C	Core Casks	3. Certification For OJT					4. Proficiency Codes Used to Indicate Training/Information Provided (See Atch 1)			
Tasks, Knowledge And Technical References			A	В	С	D	Е	A 3 Skill Level	B CDC		C 7 Skill Level
	5	7	Tng Start	Tng Comp	Trainee Initials	Trainer Initials	Certifier Initials	Course	5	7	Course
A2,18. GENERAL MAINTENANCE/PRODUCTION TEAM MAINTENANCE TASKS TR: Applicable Aircraft Technical Orders								Course			Course
A2.8.1. Technical order familiarization								-	-	-	-
A2.8.2 Flightline safety/ precautions/ security								-	-	-	-
A.2.8.3. Introduction to aircraft/airframe familiarization/egress								-	-	-	-
A.2.8.4. Inspect/use ground maintenance stands								-	-	-	-
A2.8.5. Dropped object prevention program (DOPP)								-	-	-	-
A2.8.6. Defensive systems (DS) familiarization (on applicable aircraft)								-	-	-	-
A2.8.7. Statically ground aircraft								-	-	-	-
A2.8.8. Inspect/operate portable external electrical								-	-	-	-
A2.8.9. Apply/disconnect external electrical power								-	-	-	-
A2.8.10. Tow aircraft											
A2.8.10.1. Perform wing/tail walker duties								-	-	-	-
A2.8.10.2. Brake Operator								-	-	-	-
A2.8.11. Perform refuel/defuel team member duties											
A2.8.11.1. Fireguard								-	-	-	-
A2.8.11.2. Panel Operator								-	-	-	-
A2.8.12. Open and close engine cowling								-	-	-	-
A2.8.13. Remove/install aircraft maintenance access								-	-	-	-
A2.8.14. Use aircraft interphone system								-	-	-	-
A2.8.15. Perform aircraft marshaling procedures	-							_	_	_	-